

Installation Instructions

SLFWM LCD Fixed Mount



Thank you for purchasing a product of Resource International.

Warranty: Limited Lifetime on manufacturing defects and workmanship.

Specifications are subject to change without prior notice


Every effort has been made to provide accurate and error-free assembly and installation. Resource International disclaims liability for any difficulties arising from the interpretation of information contained in these instructions. If Resource International products are used for purposes other than their original intent, Resource International, its distributors and retailers shall not be held responsible or liable for injuries or property damage, direct, indirect, or consequential, which may arise from the inability to use this product safely, properly, and in the manner for which it has been designed and manufactured. Warranty does not apply to products which have been lost, damaged by misuse, abuse, or accident.

- Universal VESA mount
- Low profile: only 1/2" from wall
- Easy to install: sliding plate operation
- Accepts security hardware
- 40 lbs (18.1 Kg) capacity

IMPORTANT: Consult a qualified installer if you have any questions regarding the proper installation of this wall mount system.

Questions? 1-877-793-4340

SLFWM



ID	Description	Qty
1	Monitor Plate	1
2	Wall Plate	1
3	Safety Screw: 10-32 X 3/8"	2
4	Wall Screw: 6mm x 50mm	2
5	Wall Anchor	2
6	Screw: 4mm x 8mm	4
7	Screw: 4mm x 12mm	4
8	Screw: 5mm x 8mm	4
9	Screw: 5mm x 12mm	4
10	Screw: 1/4" - 20 x 1/2"	4



Step 1

Determine the desired location for the monitor.

Important: Make sure there is adequate mounting space available for the monitor, considering the monitor dimensions.

The SLFWM is supplied with the necessary hardware for either Wooden Stud Mounting or Masonry Mounting. Determine your mounting type and proceed accordingly.




Fig. 1

Wooden Stud Mounting: Using an electronic stud finder, locate the center of the wooden stud.

Position the Wall Plate (2) in desired mounting location over stud.

Level the Wall Plate with a bubble level, and then using the wall bracket as a template, mark mounting hole locations over the center of the stud.

Drill 2 mounting holes into the stud using a 5/32" drill bit.

Step 2

Securely mount Wall Plate with supplied Wall Screws (4). (Fig. 1)




Fig. 2

Step 3

Attach Monitor Plate to back of the monitor with 4mm or 5mm supplied hardware. (6-9) (Fig. 2) Check the monitor's owners manual for correct length screw to use.

Caution: Never force screws into the monitor, as damage may occur.

Step 4

Carefully position monitor so that Wall and Monitor Plates are vertically aligned, with the bottom of Monitor plate overlapping the top of the Wall Plate by approximately 1".

Gently lower monitor into position, sliding the two plates together until the Monitor Plate bottoms out. (Fig. 3)

Caution: Make sure that the plates are engaged on both sides of the mount before releasing grip on monitor.

Step 5

Install two 10-32 Safety Screws (3) through bottom of Wall Plate. (Fig. 3)

Masonry Mounting: Position the Wall Plate (2) in desired mounting location on wall.

Level the Wall Plate with a bubble level, and then using the wall bracket as a template, mark mounting hole locations on wall.

Drill 2 mounting holes using a 5/16" masonry bit. Insert Wall Anchors (5) into the mounting holes, and lightly tap them flush to the wall with a hammer.

Caution: Wall Anchors should only be used for masonry mounting. NEVER use wall anchors to mount the SLFWM to drywall.

Fig. 3

